



Dry Fit Instructions

TOOLS:

1. Dry Fit Templates (enclosed)
2. Scissors
3. Sharpie Marker
4. Worksheet (Enclosed)

INSTRUCTIONS:

5. Use scissors to cut out each templated part leaving as much clear Vinyl Film as possible around each part in case you need to mark a size increase.
6. Place each part on your boat in the exact position to which it will be applied. If there is a molded in pattern on your boat then the parts should be aligned to the pattern.
7. Use the enclosed worksheet to identify where each part number is to go in the boat.
8. Verify each piece fits.
9. If a change is needed it is recommended to show the change clearly with your marker and make a notation of the area changed on the Vinyl Film.
10. If a size increase is needed beyond the space left after cutting out each part you can attach more Vinyl Film to the edge and tape from the underside. Then make your tracing. You can also show a notation of the area to be grown and by how much without having to tape more Vinyl Film to it.
11. Revisions should be made clearly as possible so that additional revisions will not be required.
12. If no changes are required there is no need to send the dry fits back.
13. If dry fits are correct "as is" then you can simply reply to your original "drawing approval email" and follow the instructions provided by the sales representative.

If ever you have any questions it is always best to call or email customerservice@seadek.com.

SeaDek Marine Products
5440 Schenck Ave, Rockledge, FL 32955
Ph: 321-632-4466 / Fax: 321-632-7019
E-mail: customerservice@seadek.com